



# EDSWG EDSWG/A

CE 0682

**GatesPlus**

1300 121 666  
www.gatesplus.com.au


## Quick Guide to EDSWG And EDSWG/A Key pad

### Keypad

IS0339A03MM\_10-03-2016



Nice SpA  
Oderzo TV Italia  
info@niceforyou.com



To program this key pad to a SMXI receiver (Mode 1) Press and hold button A on the receiver until the LED B lights up SOLID.

On the keypad enter

1 – 1 then **hold** the A button until you see 3 flashes on the receiver LED

A=Program button  
B=Status LED

## PROGRAMMING YOUR PERSONAL SECURITY CODE

Factory codes for channels    A (1-1-A)  
  B (2-2-B)  
  C (3-3-C)

Your new security code can be up to 8 digits long. It is recommended that you change the security code to all 3 outputs. To change the code, follow the steps below.

1. Press and HOLD the 0 button
2. Press and release the A button
3. Release the 0 button
4. Enter 1 – 1 – A
5. Enter your new security code \_\_\_\_\_
6. Press A
7. Enter your new security code \_\_\_\_\_
8. Press A

3 beeps from the keypad confirms the new code is programmed.  
Follow the 8 steps above changing the factory codes as listed above.